

CASEWORK GENERAL NOTES:

Revised 12-19-2013

1.	FULL HEIGHT STORAGE CABINETS (UNO) - SHALL BE 2'-0" DEEP. - 2'-0" MAXIMUM DOOR WIDTH - WARDROBE CABINETS TO BE 2'-0" DEEP. - PROVIDE (5) ADJ PIPES	11.	COUNTERTOP SUPPORT BRACKETS ARE PROVIDED BY THE CASEWORK SUPPLIER. PROVIDE WALL BLOCKING AT EACH SUPPORT.
2.	BASE AND WALL - WALL CROWN TO BE 1/4" MAXIMUM. - BASE TO BE 1/4" MAXIMUM. - (1) 1/4" MAXIMUM. - (2) 1/4" MAXIMUM. - (3) ALL OTHERS, AND	12.	COORDINATE LOCATION OF ALL UNDERCOUNTER SUPPORT WITH OWNER FURNISHED/OWNER INSTALLED EQUIPMENT.
3.	SEE INTERIOR FOR FINISHED TOPS. WHERE FILLER IS REQUIRED, IT SHALL BE EQUAL IN SIZE AT BOTH ENDS OF THE RUN.	13.	NO EXPOSED FASTENERS ON CASEWORK (UNO).
4.	PROVIDE LOCKS ON ALL DRAWERS WHERE INDICATED.	14.	ALL EXPOSED METAL CLIP ANGLES AND BRACKETS TO BE PAINTED TO MATCH CASEWORK.
5.	PROVIDE CONTINUOUS TOP OF BACKSPLASH/SIDESPLASHES.	15.	ALL EXPOSED AND SEMI-EXPOSED SURFACES OF CASEWORK, SHELVING, BASE, FULL HEIGHT AND UPPER WALL CABINETS, AND FINISHED END PANELS ARE PLAM (UNO).
6.	PROVIDE 1" THICK SHELVING WHERE CABINETS ARE OVER 3'-0" WIDE.	16.	FIELD VERIFY SPACE AVAILABLE AT CABINET LOCATIONS PRIOR TO CASEWORK FABRICATION.
7.	PROVIDE GROMMETS AT WORKSTATIONS, INCLUDING NURSE STATIONS, RECEPTION DESKS AND OTHER WORK COUNTERS. CUT IN FIELD-PROVIDE ONE PER ELECTRICAL DEVICE BELOW COUNTER-COORDINATE LOCATIONS WITH OWNER. COLOR TO BE SELECTED BY ARCHITECT. SEE SPECIFICATION FOR GROMMET TYPES AND SIZES.	17.	RETURN BACKSPLASH AT SIDEWALLS (UNO).
8.	PROVIDE A 2" RADIUS EDGE (IN PLAN) AT ALL OUTSIDE, EXPOSED COUNTERTOP CORNERS (UNO). ALL PLAM COUNTERTOPS SHALL HAVE A 1 1/4" THICK PLAM SQUARE EDGE NOSING (UNO).	18.	TUCK WALL COVERING BEHIND ALL BACKSPLASHES.
9.	ALL COUNTERTOPS ARE 2'-1" DEEP (UNO).	19.	ALL CABINETS TO RECEIVE BASE SCHEDULED FOR ROOM (UNO).
10.	PROVIDE PLYWOOD BACKUP AT ALL GCM COUNTERTOPS.	20.	COORDINATE ALL SWITCHES, UNDER-CABINET LIGHT FIXTURES AND UNDERCOUNTER RECEPTACLES WITH THE ELECTRICAL CONTRACTOR.
		21.	PROVIDE HANGING FILE EDGE/HARDWARE WHERE FILE DRAWERS ARE INDICATED.
		22.	PROVIDE A 1/4" GAP BETWEEN BOTTOM EDGE OF COUNTERTOP AND TOP EDGE OF DOOR FRONTS/DOORS OF CABINETS.
		23.	REFER TO FINISH PLAN GENERAL NOTES FOR CASEWORK FINISHES (UNO).
		24.	BASE AS SCHEDULED (UNO).
		25.	PLAM COUNTERTOPS TO RECEIVE 3mm FLAT PVC EDGE (UNO).