

## CASEWORK GENERAL NOTES:

Revised 12-19-2013

- |  |  |
|--|--|
| <p>1. FULL HEIGHT STORAGE CABINETS (UNO)<br/>- SHALL BE 2'-0" DEEP.<br/>- 2'-0" MAXIMUM DOOR WIDTH.<br/>- WARDROBE CABINETS TO 2'-0" DEEP.<br/>- PROVIDE (5) ADJ PLAM</p> <p>2. BASE AND WALL<br/>- WALL CABINETS<br/>- BASE<br/>- (1)<br/>- (2) S, AND<br/>- (3) A</p> <p>3. SEE INTER WHERE FILL ED TOPS.<br/>BOTH ENDS C VAL IN SIZE AT</p> <p>4. PROVIDE LOCKS WHERE INDICATED.</p> <p>5. PROVIDE CONTINUOL JACKSPASH/SIDESPLASHES.</p> <p>6. PROVIDE 1" THICK SHELV CABINETS ARE OVER 3'-0" WIDE.</p> <p>7. PROVIDE GROMMETS AT WORKSTATIONS, INCLUDING NURSE STATIONS, RECEPTION DESKS AND OTHER WORK COUNTERS. CUT IN FIELD-PROVIDE ONE PER ELECTRICAL DEVICE BELOW COUNTER-COORDINATE LOCATIONS WITH OWNER. COLOR TO BE SELECTED BY ARCHITECT. SEE SPECIFICATION FOR GROMMET TYPES AND SIZES.</p> <p>8. PROVIDE A 2" RADIUS EDGE (IN PLAN) AT ALL OUTSIDE, EXPOSED COUNTERTOP CORNERS (UNO). ALL PLAM COUNTERTOPS SHALL HAVE A 1 1/4" THICK PLAM SQUARE EDGE NOSING (UNO).</p> <p>9. ALL COUNTERTOPS ARE 2'-1" DEEP (UNO).</p> <p>10. PROVIDE PLYWOOD BACKUP AT ALL SSM COUNTERTOPS.</p> | <p>11. COUNTERTOP SUPPORT BRACKETS ARE PROVIDED BY THE CASEWORK SUPPLIER. PROVIDE WALL BLOCKING AT EACH SUPPORT.</p> <p>12. COORDINATE LOCATION OF ALL UNDERCOUNTER SUPPORT WITH OWNER FURNISHED/OWNER INSTALLED EQUIPMENT.</p> <p>13. NO EXPOSED FASTENERS ON CASEWORK (UNO).</p> <p>14. ALL EXPOSED METAL CLIP ANGLES AND BRACKETS TO BE PAINTED TO MATCH CASEWORK.</p> <p>15. ALL EXPOSED AND SEMI-EXPOSED SURFACES OF CASEWORK, SHELVING, BASE, FULL HEIGHT AND UPPER WALL CABINETS, AND FINISHED END PANELS ARE PLAM (UNO).</p> <p>16. FIELD VERIFY SPACE AVAILABLE AT CABINET LOCATIONS PRIOR TO CASEWORK FABRICATION.</p> <p>17. RETURN BACKSPLASH AT SIDEWALLS (UNO).</p> <p>18. TUCK WALL COVERING BEHIND ALL BACKSPLASHES.</p> <p>19. ALL CABINETS TO RECEIVE BASE SCHEDULED FOR ROOM (UNO).</p> <p>20. COORDINATE ALL SWITCHES, UNDER-CABINET LIGHT FIXTURES AND UNDERCOUNTER RECEPTACLES WITH THE ELECTRICAL CONTRACTOR.</p> <p>21. PROVIDE HANGING FILE EDGE/HARDWARE WHERE FILE DRAWERS ARE INDICATED.</p> <p>22. PROVIDE A 1/4" GAP BETWEEN BOTTOM EDGE OF COUNTERTOP AND TOP EDGE OF DOOR FRONTS/DOORS OF CABINETS.</p> <p>23. REFER TO FINISH PLAN GENERAL NOTES FOR CASEWORK FINISHES (UNO).</p> <p>24. BASE AS SCHEDULED (UNO).</p> <p>25. PLAM COUNTERTOPS TO RECEIVE 3mm FLAT PVC EDGE (UNO).</p> |
|--|--|

**REVIEW  
AND EDIT  
BEFORE  
ISSUING**